

ID.NO.	PART NO.	DESCRIPTION	Q'TY
1A	H5GSP-0FF5	Coil Spring Assembly-K=0.79	1
or 1B	H5GSP-0FF5 -H	Coil Spring Assembly-K=1.17	1
or 1C	H5GSP-0FF5 -S	Coil Spring Assembly-K=0.65	1
1-1	H5FNA-2162-100	Adjuster Assembly	1
1-2	M5GAE-0PB021	Spring Guide	1
1-3	M5FPV-2311-000	Spring Sheath	1
1-4A	MF2350-200-079	Coil Spring-K=0.79	1
or 1-4B	MF2350-200-117	Coil Spring-K=1.17	1
or 1-4C	MF2350-200-065	Coil Spring-K=0.65	1
2	M5FH2-2340-000	Dust cap	1
3	M5GAEJC130	Compression Rod	2
4	M5GSPB-420-5	Top-Out Bumper	2
5	H5GCR0FM5TA2600	Crown Assembly(Head Parts 25.4mm)	1
6	M5GSPB-415	Top-Out Bumper	2
7	M5GAEMB50	Bottom-Out spacer	2
8	H5GFRF04-0000	Outer Leg Assembly	1



10'CAPA-T-24"(50) SPARE PARTS LIST

